

CL1 Karting Data Kit Recommended Settings for Mobile Phones and Tablets



When utilizing a mobile phone and tablet with the D3 app, Racepak recommends the following settings, in order to optimize the user experience.

Android Devices

Do Not Disturb

- Apps
- Settings
- Sound
- Do not disturb – Slide button to left

Notifications

- Apps
- Settings
- Notifications – Turn off all notifications with the exception of Racepak D3 Karting

Screen Brightness

- Apps
- Settings
- Display
- Brightness – Slide bar fully to right

Screen Timeout

- Apps
- Settings
- Display
- Screen Time Out – After 10 minutes of inactivity

IOS Devices

Do Not Disturb

- Settings
- Do Not Disturb
- Manual – Slide right to turn On

Notifications

- Settings
- Notifications
- Activity or App Store – Allow Notifications slide button to Right
- Return to Notifications settings, select D3 and slide button to Right

Screen Brightness

- Settings
- Display and Brightness
- Brightness – Slide button to Right

Screen Timeout

- Settings
- Display and Brightness
- Auto-Lock – Set to 10 minutes